

BOSKA®

SINCE 1896

Food Tools for Life

BBQ tools - EN

Description

BBQ tools are utensils specifically designed for preparing food on the barbecue. BOSKA offers various BBQ tools such as tongs, tweezers, spatulas, and flippers. These tools provide a safe and efficient way to handle and serve food from the barbecue.

Here's how to use it:

1. **Choose the right tool:** Select the BBQ tool that best suits the task, such as tongs for handling larger pieces of meat or turning them, or tweezers for turning smaller pieces of meat, fish, or vegetables, etc.
2. **Hold the tool:** Grip the BBQ tool firmly by the handle.
3. **Use the tool:** Use the tool to safely turn, pick up, or move food on the barbecue.
Note: The handle and head of BBQ tools can become hot when held above the barbecue for a long time.

Warnings



CAUTION

SHARP OBJECT(S) INSIDE
HANDLE WITH CARE

KEEP OUT OF REACH OF CHILDREN